


# CM310

## Quad Serial Port utilityModule

### User's Manual



RTD Embedded Technologies, Inc.

*"Accessing the Analog World"®*

BDM-610020016  
Rev. B

---

---

# CM310

## Quad Serial Port utilityModule

### User's Manual

---

---



**RTD Embedded Technologies, INC.**  
103 Innovation Blvd.  
State College, PA 16803-0906

Phone: +1-814-234-8087  
FAX: +1-814-234-5218

E-mail  
sales@rtd.com  
techsupport@rtd.com

web site  
<http://www.rtd.com>

### Revision History

08/17/1999	Initial release.
09/14/1999	Pull down resister jumpers added
10/18/1999	Self-explanatory diagnostic program included
10/29/1999	Include 24Mhz clock to support 1.5 Mbps transceiver operation
02/01/2000	Changed SW2 to 8 position and made SW3 and SW4 terminations
02/02/2000	Reversed RS-422 signal names polarity (+/-)
02/08/2000	Removed 25 pin D connector for RS-422 mode
Rev. A	New Manual Naming Method
Rev. B (02/20/2008)	- Corrected default IRQ jumper settings to match current shipping configuration. - Resolved some ambiguity in the COM port numbering - Added a note about IRQ sharing and OS limitations

Published by:

RTD Embedded Technologies, Inc.  
103 Innovation Blvd.  
State College, PA 16803-0906

Copyright 1999, 2002, 2003, 2008 by RTD Embedded Technologies, Inc.  
All rights reserved

The RTD Logo is a registered trademark of RTD Embedded Technologies. cpuModule and utilityModule are trademarks of RTD Embedded Technologies. PhoenixPICO and PheonixPICO BIOS are trademarks of Phoenix Technologies Ltd. PS/2, PC/XT, PC/AT and IBM are trademarks of International Business Machines Inc. MS-DOS, Windows, Windows 95, Windows 98 and Windows NT are trademarks of Microsoft Corp. PC/104 is a registered trademark of PC/104 Consortium. All other trademarks appearing in this document are the property of their respective owners.

# Table of Contents

<b>CHAPTER 1 INTRODUCTION.....</b>	<b>6</b>
CM310 QUAD SERIAL PORT UTILITYMODULE.....	6
CONFIGURING THE UTILITYMODULE.....	7
<b>CHAPTER 2 INSTALLING THE UTILITYMODULE.....</b>	<b>13</b>
RECOMMENDED PROCEDURE .....	13
FINDING PIN 1 OF CONNECTORS .....	13
PC/104 BUS CONNECTORS, CN1 AND CN2.....	15
FIRST COM PORT, CN3 .....	16
RS232 SERIAL PORT (DEFAULT) .....	17
RS422 OR RS485 SERIAL PORT.....	18
SECOND COM PORT, CN4.....	19
THIRD COM PORT, CN5 .....	19
FOURTH COM PORT, CN6.....	19
CM310 COMMON REGISTERS.....	20
<b>CHAPTER 3 USING THE UTILITYMODULE.....</b>	<b>22</b>
COM PORTS .....	22
1.5 MBPS SUPPORT .....	22
INTERRUPT SHARING .....	22
DIAGNOSTIC SOFTWARE .....	23
POWER PROTECTION CIRCUITRY .....	24
<b>CHAPTER 4 RETURN POLICY AND WARRANTY.....</b>	<b>25</b>
RETURN POLICY .....	25
LIMITED WARRANTY.....	26

## Table of Tables

TABLE 1 DEFAULT JUMPER SETTINGS .....	9
TABLE 2 SWITCH AND JUMPER TABLES.....	10
TABLE 3 BASE ADDRESS TABLE FOR COM PORTS .....	12
TABLE 4 CONNECTOR TABLE .....	14
TABLE 5 PC/104 XT BUS CONNECTOR.....	15
TABLE 6 PC/104 AT BUS CONNECTOR .....	16
TABLE 7 CONNECTOR CN3 IN RS-232 MODE (I).....	17
TABLE 8 CONNECTOR CN3 IN RS-232 MODE (II).....	17
TABLE 9 CONNECTOR CN3 IN RS422/485 MODE (I).....	18
TABLE 10 CONNECTOR CN3 IN RS422/485 MODE (II).....	18

## Table of Figures

FIGURE 1 SWITCH & JUMPER LOCATIONS.....	8
FIGURE 2 CONNECTOR LOCATIONS.....	14

# Chapter 1 INTRODUCTION

---

This manual gives information on the CM310 Quad Serial Port utilityModule. This module supports four versatile serial ports for the 16 (Intel) bus interface type, with jumper configurable IRQ lines and I/O addresses for your PC/104 applications.

## ***CM310 Quad Serial Port utilityModule***

The CM310 Quad Serial Port utilityModule was designed to provide four versatile serial ports to support the Real Time Devices cpuModules and other standard PC/104 processor modules.

### **Features**

The following are major features of the CM310 utilityModule.

- Compatibility with the Industry Standard 16C550
- 1.5 Mbps baud transmit/receive operation (24Mhz)
- 16 byte transmit FIFO/16 byte receive FIFO with error flags
- Independent transmit and receive control
- Standard modem interface
- Jumper selectable interrupt line, base address, RS232/RS422-485 mode per port
- Jumper selectable enable/disable per port
- Includes 42 different selectable I/O base addresses
- Extended temperature range: -40 to +85C
- Low power-consumption
- Typical from single +5V power supply

### Software Included

- Self-explanatory diagnostic program included

## Connectors and Switches

Connectors provided are:

- CN1: PC/104 Bus (XT)
- CN2: PC/104 Bus (AT)
- CN3: First COM port
- CN4: Second COM port
- CN5: Third COM port
- CN6: Fourth COM port

Switches provided are:

- SW1: Base address selection
- SW2: Enable/Disable and RS232/RS422-486 mode
- SW3: First and second port RS422/485 termination
- SW4: Third and fourth port RS422/485 termination

## Recommended Cables

XK-CM310

## General Specifications

- Dimensions: 3.8 x 3.9 x 0.6" (97 x 100 x 16 mm)
- Weight (mass): 3.0 ounces (85 grams)
- 6-layer PCB
- Operating conditions:
- Temperature: -40 - +85 degrees C
- Relative humidity: 0 - 95%, non-condensing
- Storage temperature: -55 to +125 degrees C

## ***Configuring the utilityModule***


The following sections contain information on configuring the utilityModule.

Please read this entire section before attempting to use the utilityModule!

# Jumpers and Switches

## Locations

The figure below shows switch and jumper locations.



*Figure 1 Switch & Jumper Locations*

## Default Settings

The utilityModule is delivered from the factory configured according to the following table.

**Table 1 Default Jumper Settings**

<b>Jumper</b>	<b>Setting</b>	<b>Function</b>
JP1 G jumper	Not Installed Installed	Interrupts Disabled for 1 <sup>st</sup> COM port 1K pull down resistor on IRQ4 line
JP2 G jumper	Not Installed Installed	Interrupts Disabled for 2 <sup>nd</sup> COM port 1K pull down resistor on IRQ3 line
JP3 G jumper	Not Installed Installed	Interrupts Disabled for 3 <sup>rd</sup> COM port 1K pull down resistor on IRQ5 line
JP4 G jumper	Not Installed Installed	Interrupts Disabled for 4 <sup>th</sup> COM port 1K pull down resistor on IRQ10 line
JP5 CLK jumper	2-3 installed	1.8432 MHz input clock is selected
SW1	All down	I/O base addresses at 3E8, 2E8, 280, 288 for 1 <sup>st</sup> , 2 <sup>nd</sup> , 3 <sup>rd</sup> and 4 <sup>th</sup> COM port respectively
SW2	1-4 up 5-8 down	All COM ports enabled All ports in RS232 mode
SW3	All up	No serial termination resistors
SW4	All up	No serial termination resistors

## Descriptions

The following table describes the functions of the jumpers.

**Table 2 Switch and Jumper tables**

<b>Jumper</b>	<b>Use</b>										
<b>JP 1</b>	IRQ selection for 1 <sup>st</sup> COM Port (CN3) G setting: jumper installed = 1K pull down resistor for the selected IRQ Jumper removed = no pull down for the selected IRQ										
<b>JP 2</b>	IRQ selection for 2 <sup>nd</sup> COM Port (CN4) G setting: jumper installed = 1K pull down resistor for the selected IRQ Jumper removed = no pull down for the selected IRQ										
<b>JP3</b>	IRQ selection for 3 <sup>rd</sup> COM Port (CN5) G setting: jumper installed = 1K pull down resistor for the selected IRQ Jumper removed = no pull down for the selected IRQ										
<b>JP 4</b>	IRQ selection for 4 <sup>th</sup> COM Port (CN6) G setting: jumper installed = 1K pull down resistor for the selected IRQ Jumper removed = no pull down for the selected IRQ										
<b>JP5</b>	Input clock selection for serial ports 1-2 = select 24 MHz input clock to UART 2-3 = select 1.8432 MHz input clock to UART										
<b>SW1</b>	I/O base address switch. See Base Address Table for details										
<b>SW2 Positions 1-4</b>	Up = enable serial port Down = disable serial port <table border="0"> <tr> <td>Switch position</td> <td>Port</td> </tr> <tr> <td>1</td> <td>CN3</td> </tr> <tr> <td>2</td> <td>CN4</td> </tr> <tr> <td>3</td> <td>CN5</td> </tr> <tr> <td>4</td> <td>CN6</td> </tr> </table>	Switch position	Port	1	CN3	2	CN4	3	CN5	4	CN6
Switch position	Port										
1	CN3										
2	CN4										
3	CN5										
4	CN6										
<b>SW2 Positions 5-8</b>	Up = RS422/485 mode Down = RS232 mode <table border="0"> <tr> <td>Switch position</td> <td>Port</td> </tr> <tr> <td>5</td> <td>CN3</td> </tr> <tr> <td>6</td> <td>CN4</td> </tr> <tr> <td>7</td> <td>CN5</td> </tr> <tr> <td>8</td> <td>CN6</td> </tr> </table>	Switch position	Port	5	CN3	6	CN4	7	CN5	8	CN6
Switch position	Port										
5	CN3										
6	CN4										
7	CN5										
8	CN6										
<b>SW3</b>	Up = Don't use on-board serial termination resistor Down = Use 120 on-board serial termination resistor for RS422/485 mode <table border="0"> <tr> <td>Switch position</td> <td>Port and signal</td> </tr> <tr> <td>1</td> <td>CN3 -- RxD</td> </tr> <tr> <td>2</td> <td>CN3 -- CTS</td> </tr> <tr> <td>3</td> <td>CN4 -- RxD</td> </tr> <tr> <td>4</td> <td>CN4 -- CTS</td> </tr> </table>	Switch position	Port and signal	1	CN3 -- RxD	2	CN3 -- CTS	3	CN4 -- RxD	4	CN4 -- CTS
Switch position	Port and signal										
1	CN3 -- RxD										
2	CN3 -- CTS										
3	CN4 -- RxD										
4	CN4 -- CTS										

<b>SW4</b>	Up = Don't use on-board serial termination resistor	
	Down = Use 120 on-board serial termination resistor for RS422/485 mode	
	Switch position	Port and signal
	1	CN5 -- RxD
	2	CN5 -- CTS
3	CN6 -- RxD	
4	CN6 -- CTS	

**Table 3 Base address table for COM ports**

COM port addresses –base address in Hex for eight 8-bit registers							
SW1-4	SW-3	SW-2	SW-1	CN3	CN4	CN5	CN6
Down	Down	Down	Down	3E8	2E8	280	288
Down	Down	Down	Up	280	288	290	298
Down	Down	Up	Down	290	298	2A0	2A8
Down	Down	Up	Up	2A0	2A8	2B0	2B8
Down	Up	Down	Down	100	108	110	118
Down	Up	Down	Up	120	128	130	138
Down	Up	Up	Down	140	148	150	158
Down	Up	Up	Up	160	168	170	178
Up	Down	Down	Down	100	108	500	508
Up	Down	Down	Up	120	128	520	528
Up	Down	Up	Down	280	288	680	688
Up	Down	Up	Up	290	298	690	698
Up	Up	Down	Down	2A0	2A8	6A0	6A8
Up	Up	Down	Up	2B0	2B8	6B0	6B8
Up	Up	Up	Down	3E8	2E8	7E8	6E8
Up	Up	Up	Up	3F8	2F8	3E8	2E8

## Chapter 2 **INSTALLING THE UTILITYMODULE**

---

Since the utilityModule uses a PC/104 stackthrough bus, the only hardware installation you will do is placing the module to the PC/104 stack. To do this, you will connect the PC/104 bus connector with the matching connector of another module.

### ***Recommended Procedure***

We recommend you follow the procedure below to ensure that stacking of the modules does not damage connectors or electronics.

- Turn off power to the PC/104 system or stack.
- Select and install standoffs to properly position the utilityModule on the PC/104 stack.
- Touch a grounded metal part of the stack to discharge any buildup of static electricity.
- Remove the utilityModule from its anti-static bag.
- Check that keying pins in the PC/104 bus connector are properly positioned.
- Check the stacking order: make sure an XT bus card will not be placed between two AT bus cards, or it will interrupt the AT bus signals.
- Hold the utilityModule by its edges and orient it so the bus connector pins line up with the matching connector on the stack.
- Gently and evenly press the utilityModule onto the PC/104 stack.

---

**CAUTION:** Do not force the module onto the stack! Wiggling the module or applying too much force may damage it. If the module does not readily press into place, remove it, check for bent pins or out-of-place keying pins, and try again.

---

Connecting the utilityModule


The following sections describe connectors of the utilityModule.

### ***Finding Pin 1 of Connectors***

A white area silk-screened on the PC board indicates pin 1 of connectors. A square solder pad visible on the bottom of the PC board also indicates it.

## Locations

The figure below shows connector locations.



**Figure 2 Connector Locations**

**Table 4 Connector Table**

Connector	Function	Size
CN1	PC/104 XT Bus	64 pin
CN2	PC/104 AT Bus	40 pin
CN3	1 <sup>st</sup> COM port	10 pin
CN4	2 <sup>nd</sup> COM port	10 pin
CN5	3 <sup>rd</sup> COM port	10 pin
CN6	4 <sup>th</sup> COM port	10 pin

## PC/104 Bus Connectors, CN1 and CN2

Connectors CN1 and CN2 provide PC/104 bus connections. CN1 carries XT bus signals, and CN2 carries additional signals for the AT bus. The signals on CN1 and CN2 conform to the IEEE P966 standard for the PC/104 bus.

The following tables list the connector pinouts:

**Table 5 PC/104 XT Bus Connector**

PC/104 XT Bus Connector, CN1		
Pin	Row A	Row B
1	IOCHCHK*	0V
2	SD7	RESETDRV
3	SD6	+5V
4	SD5	IRQ9
5	SD4	-5V
6	SD3	DRQ2
7	SD2	-12V
8	SD1	ENDXFR*
9	SD0	+12V
10	IOCHRDY	(KEYING PIN)
11	AEN	SMEMW*
12	SA19	SMEMR*
13	SA18	IOW*
14	SA17	IOR*
15	SA16	DACK3
16	SA15	DRQ3
17	SA14	DACK1*
18	SA13	DRQ1
19	SA12	REFRESH
20	SA11	SYSCLK
21	SA10	IRQ7
22	SA9	IRQ6
23	SA8	IRQ5
24	SA7	IRQ4
25	SA6	IRQ3
26	SA5	DACK2*
27	SA4	TC
28	SA3	BALE
29	SA2	+5V
30	SA1	OSC
31	SA0	0V
32	0V	0V

**Table 6 PC/104 AT Bus Connector**

<b>PC/104 AT Bus Connector, CN2</b>		
<b>Pin</b>	<b>Row C</b>	<b>Row D</b>
0	0V	0V
1	SBHE*	MEMCS16*
2	LA23	IOCS16*
3	LA22	IRQ10
4	LA21	IRQ11
5	LA20	IRQ12
6	LA19	IRQ15
7	LA18	IRQ14
8	LA17	DACK0*
9	MEMR*	DRQ0
10	MEMW*	DACK5*
11	SD8	DRQ5
12	SD9	DACK6*
13	SD10	DRQ6
14	SD11	DRQ6
15	SD12	DRQ7
16	SD13	+5V
17	SD14	MASTER*
18	SD15	0V
19	(KEYING PIN)	0V

---

**Note:** Two locations on the bus have mechanical keying pins to help prevent misconnection of the PC/104 bus. These keying pins are a part of the PC/104 standard, and we strongly recommend you leave them in place.

If you have other modules without keying pins, we suggest you modify them to include keying.

---

### ***First COM port, CN3***

The first serial port is implemented on connector CN3. It can be configured as a PC compatible full duplex RS232 port or as half- or full duplex RS422 or RS485 through mode SW3. The I/O address is configurable in respect to SW1 address table, and corresponding interrupt is also selectable through jumper JP1 to be IRQ3, IRQ4, IRQ5, IR6, IRQ7, IRQ9, IRQ10, IRQ11, IRQ12, IRQ14 and IRQ15. But you need to make sure that there are no resource conflicts on the I/O base address and interrupt line you choose.

The serial port is implemented with a 16C550-compatible UART (Universal Asynchronous Receiver/Transmitter). This UART is capable of baud rates up to 115.2K.

## RS232 Serial Port (Default)

The full-duplex RS232 mode is the default setting on the utilityModule. With this mode enabled, connector CN3 must be connected to RS232 compatible devices. The following table gives the connector pinout and shows how to connect to an external serial connector, either DB25 or DB9 compatible.

### Connector CN3 in RS-232 Mode

**Table 7 Connector CN3 in RS-232 Mode (I)**

CN3 Pin	Signal	Function	In/out	DB25	DB9
1	DCD	Data Carrier Detect	In	8	1
2	DSR	Data Set Ready	In	6	6
3	RXD	Receive Data	In	3	2
4	RTS	Request To Send	Out	4	7
5	TXD	Transmit Data	Out	2	3
6	CTS	Clear To Send	In	5	8
7	DTR	Data Terminal Ready	Out	20	4
8	RI	Ring Indicate	In	22	9
9,10	GND	Signal Ground	--	7	5

Facing the connector pins, the pinout is pictured in the following,

**Table 8 Connector CN3 in RS-232 Mode (II)**

9	7	5	3	1
GND	DTR	TXD	RXD	DCD
GND	RI	CTS	RTS	DSR
10	8	6	4	2

## RS422 or RS485 Serial Port

You can change the mode switch to set the first port as RS422 or RS485. In this case, you must connect CN3 to an RS422 or RS485 compatible device.

When using RS422 or RS485 mode, you can use the port in either half-duplex (two-wire) or full-duplex (four-wire) configurations. For half-duplex (2-wire) operation, you must connect RXD+ to TDX+, and connect RXD- to TXD-.

---

Note! A 120-ohm termination resistor is provided on the utilityModule. Termination is usually necessary on all RS422 receivers and at the ends of the RS485 bus. If the termination resistor is required, it can be enabled by closing corresponding bits on SW3 or SW4.

---

### RS422 and RS485 Mode Pinout

The following table gives the pinout of connector CN3 when RS422 or RS485 modes are enabled.

**Table 9 Connector CN3 in RS422/485 Mode (I)**

CN3 Pin	Signal	Function	In/out	DB9
1	RTS-	Request to send (-)	Out	1
2	RTS+	Request to send (+)	Out	6
3	RXD-	Receive Data (-)	In	2
4	TXD+	Transmit Data (+)	Out	7
5	TXD-	Transmit Data(-)	Out	3
6	RXD+	Receive Data (+)	In	8
7	CTS-	Clear to send (-)	In	4
8	CTS+	Clear to send (+)	In	9
9,10	GND	Signal Ground	--	5

Facing the connector pins, the pinout is pictured in the following,

**Table 10 Connector CN3 in RS422/485 Mode (II)**

9	7	5	3	1
GND	CTS-	TXD-	RXD-	RTS-
GND	CTS+	RXD+	TXD+	RTS+
10	8	6	4	2

## **Notes on using RS422 or RS485 Modes**

When using the serial port in RS422 or RS485 mode, the serial receiver is always enabled, however the serial transmitter is enabled and disabled under software control in the following two ways.

By default, the transmitter is enabled by manipulating the Request To Send (RTS\*) signal of the serial port controller. This signal is controlled by writing bit 1 of the Modem Control Register (MCR) as follows:

- If MCR bit 1 = 1, then RTS\* = 0, and serial transmitter is disabled
- If MCR bit 1 = 0, then RTS\* = 1, and serial transmitter is enabled

For more information on the serial port registers, including the MCR, please refer to a standard PC-AT hardware reference for the 16C550 UART, or refer to RTDUSA application note ANC102 at <http://www.rtdusa.com>

The other way to enable the serial transmitter is to write 1 to its corresponding bit of the utilityModule's internal common register 4, which sets the serial transmitter in "always on" mode. Please refer to Internal Common Register Section for detail.

## ***Second COM port, CN4***

Please refer to the previous section on the first COM port CN3 for the description on CN4.

## ***Third COM port, CN5***

Please refer to the previous section on the first COM port CN3 for the description on CN5.

## ***Fourth COM port, CN6***

Please refer to the previous section on the first COM port CN3 for the description on CN6.

## **CM310 common registers**

The utilityModule includes 5 common registers to provide additional information and software control that is not required for normal COM port operation, but may be helpful in determining the status of the board and configuring of the board. The following two sections give the location and definition of the common registers.

### **Base Address of Common Registers**

The utilityModule common registers are located 800h above the address of the first enabled COM port. That is, assuming that “X” in hex is the first enabled COM port base address, which can be any of the valid addresses listed in the Com Port Address Table, the base address for the common registers is “Y” in hex, then,

$$Y = X + 800h$$

For example, if the switches of SW4 are set all DOWN position which makes CN3 = 3E8h, CN4 = 2E8h, CN5 = 280h and CN6 = 288h, then according to the algorithm, the common registers base address (BA) will be the following depending the setting of enable switch SW2 for each serial port,

If CN3 is enabled then,

$$BA = 3E8h + 800h = BE8h$$

Else if CN3 is disabled AND CN4 is enabled then,

$$BA = 2E8h + 800h = AE8h$$

Else if CN3 and CN4 are disabled AND CN5 is enabled then,

$$BA = 280h + 800h = A80h$$

Else if CN3, CN4 and CN5 are disabled AND CN6 is enabled then,

$$BA = 288h + 800h = A88 A80h$$

Else if CN3, CN4, CN5 and CN6 are disabled then,

Common Registers are disabled

End If

## Common Register definitions

BA + 0 – Interrupt Status (Read Only)							
7	6	5	4	3	2	1	0
Reserved	Reserved	TxRDY*	RxRDY*	CN6	CN5	CN4	CN3

For each CNx bit:

0 = Not interrupting

1 = Interrupt set

TxRDY\*

0 = indicates a buffer ready for at least one of the four transmit channels

1 = indicates that all transmit buffers are full

RxRDY\*

0 = indicates one or more of the receive channels has data ready to read

1 = indicates that all receive buffers are empty

Reserved reads as 0

BA + 1 – Address Switch (Read Only)							
7	6	5	4	3	2	1	0
Reserved	Reserved	Reserved	Reserved	SW1-4	SW1-3	SW1-2	SW1-1

For each bit, see table above

0 = Down

1 = Up

Reserved reads as A to tag on the address register.

BA + 2 -- Enable/Disable Switch (Read Only)							
7	6	5	4	3	2	1	0
Reserved	Reserved	Reserved	Reserved	CN6	CN5	CN4	CN3

For each CNx bit:

0 = Port is disabled

1 = Port is enabled

Reserved reads as 0xA for clarity

BA + 3—Mode Switch (Read Only)							
7	6	5	4	3	2	1	0
Reserved	Reserved	Reserved	Reserved	CN6	CN5	CN4	CN3

For each CNx bit:

If

0 = RS-232

1 = RS-422/485

Reserved reads as 0

BA + 4-- RS-422 RTS operation (R/W)							
7	6	5	4	3	2	1	0
Reserved	Reserved	Reserved	IntSel	CN6	CN5	CN4	CN3

IntSel:

0 = MCR bit-3 controls the three state interrupt output.

1 = Overrides MCR bit-3 and interrupt outputs are enabled continuously.

Default to 0 to set COM ports in normal mode

For each CNx bit:

If Mode = RS-232 then

Not used, Reads as 0

Else If Mode = RS-422/485 then

0 = use RTS to enable transmitter, default case

1 = transmitter always on

## Chapter 3 USING THE UTILITYMODULE

---

### **COM ports**

The utilityModule features EXAR quad UART 16C550 compatible 16C554D part.

#### **EXAR Documentation**

Due to the complexity of the EXAR serial chip, it is impossible for us to reproduce all programming information in this manual. If you will be doing in-depth programming of the serial port controller, we suggest you obtain the 16C554D datasheet from the manufacturer.

The 16C554D datasheet is available on-line in electronic format as an Adobe Acrobat (. PDF) file on the EXAR website:

[www.exar.com](http://www.exar.com)

You may also contact:

EXAR Corporation

248720 Kato Road

Fremont, CA 94538

### **1.5 Mbps support**

With 24 MHz clock input selected (JP5, 1-2), the utilityModule is capable of provide data rates up to 1.5 Mbps in RS422/RS485 mode. Since RS232 standard restricts data rate to 20 Kbps, you might experience failure at higher data rate above 252 Kbps with 24 MHz clock select for the utilityModule.

### **Interrupt Sharing**

Interrupt sharing is a mechanism which allows different devices sharing same active high IRQ lines on the PC/104 bus, given that there is a interrupt sharing circuit associated with each device. The utilityModule provides interrupt-sharing circuits for all the serial ports; thus it allows sharing of one IRQ line among the serial ports in the utilityModule. However, user needs to be careful to share an IRQ line with devices in the system elsewhere, and be sure that other devices also share their IRQ lines as well. For instance, users should be aware of that the IRQ3/IRQ4 associated with serial port J3/J4 on RTDUSA cpuModule are not shareable. And if the utilityModule is in the same system with RTDUSA cpuModule, be advised not to use/share IRQ3/IRQ4 for the utilityModule unless you have serial ports on the cpuModule disabled.

Interrupt sharing in a PC/104 system requires one 1K pull-down resistor per IRQ line for all the devices that share the IRQ. Installing a G jumper in the utilityModule will pull its associated IRQ line down with 1K resistor. That is, for example, if IRQn is shared among four serial ports on the utilityModule, only one G jumper needs to be installed for IRQn line. If more than one G jumper are installed, the pull-down on IRQn line will be much stronger than expected 1K ohm, which will prevent interrupt controller from functioning correctly.

**NOTE:** Some operating systems do not support IRQ sharing for ISA devices. If the OS does not support ISA IRQ sharing, then you must assign each com port to its own IRQ.

Let consider two cases to demonstrate the concepts for the above discussion. Let us assume that IRQ5 and IRQ10 are not used and driven by other devices in the system. For the first case, IRQ10 line is shared among the four serial ports and for the second case IRQ5 is shared for port 1 and port 2, while IRQ10 is shared among port 3 and port 4.

The following two tables listed the interrupt jumper settings for each case respectively.

**Table 11 Jumper Settings for interrupt sharing Case 1**

Jumper	Setting	Function
JP1 G jumper	13-14 Installed	IRQ10 for 1 <sup>st</sup> COM port 1K pull down resister added on IRQ10 from PORT1
JP2 G jumper	13-14 Removed	IRQ10 for 2 <sup>nd</sup> COM port No pull down resister added on IRQ10 from PORT2
JP3 G jumper	13-14 Removed	IRQ10 for 3 <sup>rd</sup> COM port No pull down resister added on IRQ10 from PORT3
JP4 G jumper	13-14 Removed	IRQ10 for 4 <sup>th</sup> COM port No pull down resister added on IRQ10 from PORT4

**Table 12 Jumper Settings for interrupt sharing Case 2**

Jumper	Setting	Function
JP1 G jumper	5-6 Installed	IRQ5 for 1 <sup>st</sup> COM port 1K pull down resister added on IRQ5 from PORT1
JP2 G jumper	5-6 Removed	IRQ5 for 2 <sup>nd</sup> COM port No pull down resister added on IRQ5 from PORT2
JP3 G jumper	13-14 Installed	IRQ10 for 3 <sup>rd</sup> COM port 1K pull down resister added on IRQ10 from PORT3
JP4 G jumper	13-14 Removed	IRQ10 for 4 <sup>th</sup> COM port No pull down resister added on IRQ10 from PORT4

## **Diagnostic Software**

The companion CD for the utilityModule includes a menu driven diagnostic program. Loop back plugs are required to run this program.

## ***Power Protection Circuitry***

To reduce the risk of damage due to power-supply problems, the utilityModule includes several protective components.

### **Module Power-Supply Protection**

The utilityModule includes a component to help prevent damage due to problems with the +5Vdc power supply from the PC/104 bus. Protection is provided for:

- Over-current
- Reversed polarity
- Excessive voltage

This protection is only for the utilityModule, and will not protect other devices in a PC/104 stack.

The protective fuse is replaceable and is available from electronics suppliers. Its description and part number is:

Littelfuse Nano<sup>2</sup> SMF 1.0 amp, R451-001

---

**Caution:** Replace fuses only with parts of identical current and voltage rating.

---

## Chapter 4 RETURN POLICY AND WARRANTY

---

### ***Return Policy***

If you wish to return a product to the factory for service, please follow this procedure:

Read the Limited Warranty to familiarize yourself with our warranty policy.

Contact the factory for a Return Merchandise Authorization (RMA) number.

Please have the following available:

- Complete board name
- Board serial number
- A detailed description of the board's behavior

**List the name of a contact person**, familiar with technical details of the problem or situation, **along with their phone and fax numbers, address, and e-mail address** (if available).

**List your shipping address!!**

Indicate the shipping method you would like used to return the product to you.

*We will not ship by next-day service without your pre-approval.*

*Carefully package the product, using proper anti-static packaging.*

*Write the RMA number in large (1") letters on the outside of the package.*

*Return the package to:*

*RTD Embedded Technologies, Inc.*

*103 Innovation Blvd.*

*State College PA 16803-0906*

*USA*

## ***Limited Warranty***

RTD Embedded Technologies, Inc. warrants the hardware and software products it manufactures and produces to be free from defects in materials and workmanship for one year following the date of shipment from RTD Embedded Technologies, INC. This warranty is limited to the original purchaser of product and is not transferable.

During the one year warranty period, RTD Embedded Technologies will repair or replace, at its option, any defective products or parts at no additional charge, provided that the product is returned, shipping prepaid, to RTD Embedded Technologies. All replaced parts and products become the property of RTD Embedded Technologies. Before returning any product for repair, customers are required to contact the factory for an RMA number.

THIS LIMITED WARRANTY DOES NOT EXTEND TO ANY PRODUCTS WHICH HAVE BEEN DAMAGED AS A RESULT OF ACCIDENT, MISUSE, ABUSE (such as: use of incorrect input voltages, improper or insufficient ventilation, failure to follow the operating instructions that are provided by RTD Embedded Technologies, "acts of God" or other contingencies beyond the control of RTD Embedded Technologies), OR AS A RESULT OF SERVICE OR MODIFICATION BY ANYONE OTHER THAN RTD Embedded Technologies. EXCEPT AS EXPRESSLY SET FORTH ABOVE, NO OTHER WARRANTIES ARE EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND RTD Embedded Technologies EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED HEREIN. ALL IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES FOR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS WARRANTY. IN THE EVENT THE PRODUCT IS NOT FREE FROM DEFECTS AS WARRANTED ABOVE, THE PURCHASER'S SOLE REMEDY SHALL BE REPAIR OR REPLACEMENT AS PROVIDED ABOVE. UNDER NO CIRCUMSTANCES WILL RTD Embedded Technologies BE LIABLE TO THE PURCHASER OR ANY USER FOR ANY DAMAGES, INCLUDING ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, EXPENSES, LOST PROFITS, LOST SAVINGS, OR OTHER DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT.

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR CONSUMER PRODUCTS, AND SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

RTD Embedded Technologies, Inc.

103 Innovation Blvd.

State College PA 16803-0906

USA

Our website: [www.rtd.com](http://www.rtd.com)