


CMT36106/3106/56106/5106 Hard Drive Carrier utilityModule

User's Manual



RTD Embedded Technologies, Inc.

"Accessing the Analog World"®

BDM-610020031
Rev. E

ISO9001 and AS9100 Certified

CMT36106/3106/56105/5106
Hard Drive Carrier utilityModule
User's Manual



RTD Embedded Technologies, INC.
103 Innovation Blvd.
State College, PA 16803-0906

Phone: +1-814-234-8087
FAX: +1-814-234-5218

E-mail
sales@rtd.com
techsupport@rtd.com

web site
<http://www.rtd.com>

Revision History

Rev. A	New Manual
Rev. B	Corrected the Jumpers section in Chapter 2.
Rev. C	Added chapter 5 to describe alternate CMT36106 for various IDAN configurations Modified technical support chapter
Rev. D	Added description of CMT56106/5106
Rev. E	Added block diagram of RHD36106/3106

Published by:

RTD Embedded Technologies, Inc.
103 Innovation Blvd.
State College, PA 16803-0906

Copyright 2006 RTD Embedded Technologies, Inc.
All rights reserved
Printed in U.S.A.

The RTD Logo is a registered trademark of RTD Embedded Technologies. cpuModule and utilityModule are trademarks of RTD Embedded Technologies. MS-DOS, Windows, Windows 95, Windows 98 and Windows NT are

trademarks of Microsoft Corp. PC/104 is a registered trademark of PC/104 Consortium. All other trademarks appearing in this document are the property of their respective owners.

TABLE OF CONTENTS

CHAPTER 1 INTRODUCTION.....	1
CMT36106 AND CMT56106 IDE DRIVE CARRIER UTILITYMODULE.....	1
CMT3106 AND CMT5106 UTILITYMODULE WITH HARD DRIVE.....	1
FEATURES.....	1
CONNECTORS.....	1
RECOMMENDED CABLES.....	2
GENERAL SPECIFICATIONS.....	2
CHAPTER 2 CONFIGURING THE UTILITYMODULE.....	3
CABLE MODES.....	3
CONNECTING EXTERNAL DRIVES.....	3
JUMPERS.....	3
CHAPTER 3 INSTALLING THE UTILITYMODULE.....	5
RECOMMENDED PROCEDURE.....	5
CHAPTER 4 CONNECTING THE UTILITYMODULE.....	6
FINDING PIN 1 OF CONNECTORS.....	6
<i>Connector Locations.....</i>	<i>6</i>
CONNECTORS.....	7
PC/104 BUS CONNECTORS, CN1 AND CN2 (CMT36106 ONLY).....	7
EIDE DRIVE CONNECTOR, CN3.....	9
EIDE STACK THROUGH CONNECTOR, CN4.....	10
EIDE CABLE CONNECTOR, CN5.....	11
CHAPTER 5 CMT36106/56106 FOR SYSTEMS.....	12
CONNECTOR LOCATIONS.....	12
<i>CMT36106/56106 Connectors.....</i>	<i>13</i>
<i>RHD36106 Connectors.....</i>	<i>14</i>
CONFIGURATION JUMPERS, JP1.....	15
KEYBOARD AND PUSH-BUTTON RESET, JP2.....	15
BUS MOUSE, JP3.....	16
MULTIFUNCTION CONNECTOR, JP4.....	16
ATX POWER BUTTON, JP5.....	17
BATTERY, B1 (FACTORY INSTALLED).....	17
SOLDER JUMPER, B3 (TO BYPASS BATTERY PROTECTION DIODE).....	17
PC SPEAKER, SPK1 (FACTORY INSTALLED).....	17
PC/104 BUS CONNECTORS, CN1 AND CN2 (CMT36106 ONLY).....	17
EIDE DRIVE CONNECTOR, CN3.....	17
EIDE STACK THROUGH CONNECTOR, CN4.....	17
EIDE CABLE CONNECTOR, CN5.....	18
POWER CONNECTOR, CN6 (CMT56106 ONLY).....	18
CHAPTER 6 GETTING TECHNICAL SUPPORT.....	19
LIMITED WARRANTY.....	20

Chapter 1 INTRODUCTION

This manual gives information on the CMT36106 and CMT56106 Drive Carrier utilityModules. This module attaches to the EIDE and PC/104 connector of a cpuModule, allowing a high speed hard drive interface.

CMT36106 and CMT56106 IDE Drive Carrier utilityModule

The CMT36106 utilityModule was designed to provide an IDE hard drive or Flash drive in the PC/104 stack to support RTD's family of PC/104-*Plus* cpuModules that have integrated EIDE controllers.

The CMT56106 utilityModule is designed to support RTD's PCI-104 cpuModules. It is very similar in function to the CMT36106.

Notes: The CMT36106 and CMT56016 are not IDE controllers. They are only drive carriers. They must be used with a cpuModule that has an on-board IDE controller.

CMT3106 and CMT5106 utilityModule with Hard Drive

The CMT3106 is a CMT36016 shipped with a 2.5" form factor hard drive installed.

The CMT5106 is a CMT56016 shipped with a 2.5" form factor hard drive installed.

Features

The following are major features of the CMT36106 and CMT56106 utilityModules.

- Provides a high speed drive interface up to DMA/100 (if supported by the cpuModule)
- A standard 2.5" form factor drive can be mounted directly onto the module
- A 0.1" 40-pin connector is provided to connect to a second drive, i.e. a CD-ROM drive.
- A stack through connector is provided to allow two CMT36106 or CMT56106 drives in a system.

Connectors

Connectors provided are:

- CN1: PC/104 XT Bus (CMT36106 Only)
- CN2: PC/104 AT Bus (CMT36106 Only)
- CN3: EIDE hard drive connector
- CN4: EIDE stack through connector
- CN5: EIDE cable connector

Recommended Cables

- 40-conductor or 80-conductor EIDE cable which can be used to connect an external drive (hard drive or CD-ROM drive) to the CMT36106 or CMT56106.

General Specifications

- Dimensions: 3.8 x 3.9 x 0.6" (97 x 100 x 16 mm)
- Weight (mass): 3.0 ounces (85 grams)
- 4-layer PCB
- Operating conditions: (not including drive)
 - temperature: -40 - +85 degrees C
 - relative humidity: 0 - 95%, non-condensing
 - Storage temperature: -55 to +125 degrees C

Chapter 2 CONFIGURING THE UTILITYMODULE

The following sections contain information on configuring the utilityModule.

Please read this entire section before attempting to use the utilityModule.

Cable modes

There are two types of cables that are used for EIDE drives: a 40 conductor cable, and an 80 conductor cable. The 80 conductor cable adds a ground wire between each signal, and uses the standard 40 pin connectors. A 40 conductor cable can be used for speeds up to UDMA Mode 2 (Ultra ATA/33). An 80 conductor cable is required for higher speeds. The BIOS or operating system detects the type of cable that is attached, and selects an appropriate speed. The CMT36106/56106 can emulate either 40 conductor or 80 conductor cables based on the jumper settings.

Connecting External Drives

External EIDE drives can be connected to CN5 of the CMT36106/56106. This can be either an additional hard drive, or a CD-ROM drive. In this configuration, one of the drive must be configured as a master, and one as a slave.

When using an external drive, a 40 conductor cable is generally used, and the board configured in 40 conductor mode. If higher transfer rates are desired, 80 conductor mode can be used. The ATA specification limits an 80 conductor cable to 18 inches in length. The PC board has about 12 inches of trace, so a cable attached to CN5 in 80 conductor mode may only be 6 inches in length. Also, not all signals go to all connectors on an 80 conductor cable. The section of the cable that attaches to the drives should be used, and the remaining cable should be discarded.

Jumpers

Jumper JP1 configures the following functions:

- 40 or 80 conductor mode
- Master/Slave

Table 2.1 shows the jumper settings to select the cable mode for the CMT36106/56106. When two of these boards are used in the same system, they must both be jumpered for 40-conductor mode.

Table 2.1 Cable Mode Settings

Cable Mode	JP1		Fastest Speed
	5-6	7-8	
40-conductor	Yes	No	Ultra ATA/33
80-conductor	No	Yes	Ultra ATA/100

The first four positions of JP1 directly connect to the master/slave jumpers of the on board EIDE drive. Typical settings are shown in Table 2.2. Note that the settings may be different depending on the drive used. When two CMT36106/56016's are in a system, or a CMT36106/56016 is used with an external drive, one drive must be configured as a master, and the other drive as a slave.

Table 2.2: Drive Mode Settings

Mode	JP1 Setting (position 1-4)
Master	None
Slave	3-4
Cable Select (not recommended)	2-4

Notes: The CMT36106/56106 only can only connect to two drives. For example, if two CMT36106/56106's are in a system, a CD-ROM cannot also be connected.

Chapter 3 INSTALLING THE UTILITYMODULE

Since the utilityModule uses an EIDE stack through bus, it must be stacked directly above the cpuModule.

Recommended Procedure

We recommend you follow the procedure below to ensure that stacking of the modules does not damage connectors or electronics.

- Turn off power to the PC/104 system or stack.
- Select and install standoffs to properly position the utilityModule on the PC/104 stack.
- Touch a grounded metal part of the stack to discharge any buildup of static electricity.
- Remove the utilityModule from its anti-static bag.
- Verify the jumper settings of the utilityModule.
- Check that keying pins in the PC/104 bus connector are properly positioned (CMT36106 only).
- Hold the utilityModule by its edges and orient it so the bus connector pins line up with the matching connector on the stack.
- Gently and evenly press the utilityModule onto the PC/104 stack.

CAUTION: Do not force the module onto the stack! Wiggling the module or applying too much force may damage it. If the module does not readily press into place, remove it, check for bent pins or out-of-place keying pins, and try again.

Chapter 4 CONNECTING THE UTILITYMODULE

The following sections describe connectors of the utilityModule.

Finding Pin 1 of Connectors

A white area silk-screened on the PC board indicates the pin 1 end of connectors. A square solder pad visible on the bottom of the PC board also indicates it.

Please make certain you have correctly identified pin 1 of a connector before you connect to it and attempt to use the utilityModule.

Connector Locations

The figure below shows connector locations.




Figure 4.1 CMT36106 Connector Locations

Notes: With the exception of the PC/104 connectors, the CMT56106 connectors and connector locations are almost identical to the CMT36106.

Connectors		
Connector	Function	Size
CN1	PC/104 XT Bus (CMT36106 only)	64 pin
CN2	PC/104 AT Bus (CMT36106 only)	40 pin
CN3	EIDE Drive Connector	50 pin
CN4	EIDE Stack through Connector	44 pin
CN5	EIDE Cable Connector	40 pin
JP1	Options Jumper	8 pin

PC/104 Bus Connectors, CN1 and CN2 (CMT36106 Only)

Connectors CN1 and CN2 provide PC/104 bus connections. CN1 carries XT bus signals, and CN2 carries additional signals for the AT bus. The signals on CN1 and CN2 conform to the IEEE P966 standard for the PC/104 bus. The CMT36106 only connects to the power pins of the PC/104 bus.

The following tables list the connector pin outs:

PC/104 XT Bus Connector, CN1		
Pin	Row A	Row B
1	IOCHCHK*	0V
2	SD7	RESETDRV
3	SD6	+5V
4	SD5	IRQ9
5	SD4	-5V
6	SD3	DRQ2
7	SD2	-12V
8	SD1	ENDXFR*
9	SD0	+12V
10	IOCHRDY	(KEYING PIN)
11	AEN	SMEMW*
12	SA19	SMEMR*
13	SA18	IOW*
14	SA17	IOR*
15	SA16	DACK3
16	SA15	DRQ3
17	SA14	DACK1*
18	SA13	DRQ1
19	SA12	REFRESH
20	SA11	SYSCLK
21	SA10	IRQ7
22	SA9	IRQ6
23	SA8	IRQ5
24	SA7	IRQ4
25	SA6	IRQ3
26	SA5	DACK2*
27	SA4	TC
28	SA3	BALE
29	SA2	+5V
30	SA1	OSC
31	SA0	0V
32	0V	0V

PC/104 AT Bus Connector, CN2		
Pin	Row C	Row D
0	0V	0V
1	SBHE*	MEMCS16*
2	LA23	IOCS16*
3	LA22	IRQ10
4	LA21	IRQ11
5	LA20	IRQ12
6	LA19	IRQ15
7	LA18	IRQ14
8	LA17	DACK0*
9	MEMR*	DRQ0
10	MEMW*	DACK5*
11	SD8	DRQ5
12	SD9	DACK6*
13	SD10	DRQ6
14	SD11	DACK7*
15	SD12	DRQ7
16	SD13	+5V
17	SD14	MASTER*
18	SD15	0V
19	(KEYING PIN)	0V

Note: Two locations on the bus have mechanical keying pins to help prevent misconnection of the PC/104 bus. These keying pins are a part of the PC/104 standard, and we strongly recommend you leave them in place.

If you have other modules without keying pins, we suggest you modify them to include keying.

EIDE Drive Connector, CN3

CN3 is a 50-pin 2mm DIL connector used to attach to the board mounted hard drive. The pin out of this connector is shown below.

EIDE Hard Drive Connector, CN3			
Pin	Signal	Function	in/out
A		Option Selection Pin	
B		Option Selection Pin	
C		Option Selection Pin	
D		Option Selection Pin	
Key	n.c.		
Key	n.c.		
1	RESET*	Reset HD	out
2	GND	Ground signal	--
3	HD7	HD data 7	in/out
4	HD8	HD data 8	in/out

5	HD6	HD data 6	in/out
6	HD9	HD data 9	in/out
7	HD5	HD data 5	in/out
8	HD10	HD data 10	in/out
9	HD4	HD data 4	in/out
10	HD11	HD data 11	in/out
11	HD3	HD data 3	in/out
12	HD12	HD data 12	in/out
13	HD2	HD data 2	in/out
14	HD13	HD data 13	in/out
15	HD1	HD data 1	in/out
16	HD14	HD data 14	in/out
17	HD0	HD data 0	in/out
18	HD15	HD data 15	in/out
19	GND	Ground signal	--
20	n.c.		--
21	AEN	Address Enable	out
22	GND	Ground signal	--
23	IOW*	I/O Write	out
24	GND	Ground signal	--
25	IOR*	I/O Read	out
26	GND	Ground signal	--
27	IOCHRDY	I/O Channel Ready	in
28	BALE	Bus Address Latch Enable	out
29	n.c.		
30	GND	Ground signal	--
31	IRQ	Interrupt Request	in
32	IOCS16*	16 bit transfer	in
33	A1	Address 1	out
34	GND	Ground signal	--
35	A0	Address 0	out
36	A2	Address 2	out
37	HCS0*	HD Select 0	out
38	HCS1*	HD Select 1	out
39	LED	HDD activity LED (-)	in
40	GND	Ground signal	--
41	+5V	Logic Power	Pwr
42	+5V	Motor Power	Pwr
43	GND	Power Ground	--
44	n.c.		

EIDE Stack through Connector, CN4

CN4 is a 44-pin 2mm DIL connector is the EIDE stack through connector. The pin out of this connector is the same as pins 1-44 of CN3.

EIDE Cable Connector, CN5

CN5 is a 40-pin 0.1" DIL connector is the EIDE cable connector. The pin out of this connector is the same as pins 1-40 of CN3.

Chapter 5 CMT36106/56106 FOR SYSTEMS

For some RTD system configurations, an alternate version of the CMT36106 or CMT56106 is installed to add a battery and PC speaker to the system. The RHD36106 is also available to add a removable hard drive configuration to a system. This chapter describes the connections for the alternate CMT36106/56106 modules.

Connector Locations




Figure 5.1 CMT36106 Connector Locations




Figure 5.2 CMT56106 Connector Locations

CMT36106/56106 Connectors		
Connector	Function	Size
CN1	PC/104 XT Bus (CMT36106 only)	64 pin
CN2	PC/104 AT Bus (CMT36106 only)	40 pin
CN3	EIDE Drive Connector	50 pin
CN4	EIDE Stack through Connector	44 pin
CN5	EIDE Cable Connector	40 pin
CN6	Power Connector (CMT56106 Only)	12 pin
JP1	Configuration Jumpers	8 pin
JP2	Keyboard and Push-Button Reset	6 pin
JP3	Bus Mouse	4 pin
JP4	Multifunction Connector	10 pin
JP5	ATX Power Switch Connector (CMT56106 Only)	2 pin
B1	Battery (Factory Installed)	2 pin
B3	Solder Jumper (to bypass battery protection diode)	2 pin
SPK1	PC Speaker (Factory Installed)	2 pin




Figure 5.3 RHD36106 Connector Locations

RHD36106 Connectors		
Connector	Function	Size
CN1	PC/104 XT Bus (CMT36106 only)	64 pin
CN2	PC/104 AT Bus (CMT36106 only)	40 pin
CN3	EIDE Drive Connector	50 pin
CN4	EIDE Stack through Connector	44 pin
JP1	Configuration Jumpers	8 pin

Configuration Jumpers, JP1

The operation of JP1 is described in Chapter 2.

Keyboard and Push-Button Reset, JP2

The Keyboard and Push-Button Reset connector implements the following functions:

- AT keyboard
- System reset input

The following table gives the pinout of JP2.

Keyboard and Push-Button Reset, JP2			
Pin	Signal	Function	Input/Output
1	KBP_SPKR-	Keyboard Power (+5V)	Output
2	CPU_GND	CPU Ground	--
3	KBD	Keyboard Data	Input
4	KBC	Keyboard Clock	Output
5	RESET*	Manual push button reset	Input
6	CPU_GND	CPU Ground	--

Keyboard

An AT compatible keyboard can be connected to JP2. Usually PC keyboards come with a cable ending with a 5-pin male PS/2 connector. The following table lists the relationship between the pins on JP2 and a standard PS/2 keyboard connector.

Keyboard Connector Pins on JP2			
JP2	Signal	Function	PS/2
1	KBP_SPKR-	Keyboard Power (+5 Volts)	4
2	CPU_GND	CPU Ground	3
3	KBD	Keyboard Data	1
4	KBC	Keyboard Clock	5

System Reset

Pin 5 of JP2 allows connection of an external push-button to manually reset the system. The push-button should be normally open, and connect to ground when pushed.

Bus Mouse, JP3

The following table gives the function of the Bus Mouse connector.

Facing the connector pins, the pinout is:

Bus Mouse, JP3			
Pin	Signal	Function	Input/Output
1	KBP_SPKR-	Speaker output (+5V)	Output
2	CPU_GND	CPU Ground	--
3	MCLK	Mouse Clock	Output
4	MDATA	Mouse Data	Input/Output

Multifunction Connector, JP4

The Multifunction connector connects the following functions to the cpuModule:

- Speaker
- AT Keyboard
- Bus Mouse
- System Reset
- Battery
- ATX Power Button (CMT56106 only)

The following table gives the pinout of JP4.

Multifunction Connector, JP4			
Pin	Signal	Function	Input/Output
1	SPKR+	Speaker output (open collector)	Input
2	KBP_SPKR-	Speaker output (+5V)	Input
3	RESET*	Manual push button reset	Output
4	PWR_BUTTON	ATX Power Button	Output
5	KBD	Keyboard Data	Output
6	KBC	Keyboard Clock	Input
7	CPU_GND	CPU Ground	--
8	MCLK	Mouse Clock	Input
9	BAT+	Battery output	Output
10	MDATA	Mouse Data	Input/Output

Notes: Pin 4, the ATX Power Button is only connected on the CMT56106. On the CMT36106, this pin is not connected.

ATX Power Button, JP5

Power Button, JP5			
Pin	Signal	Function	Input/Output
1	GND	Ground	--
2	PWR_BUTTON	Soft Power Button	Input

Battery, B1 (Factory Installed)

Connection B1 on the CMT36106/56106 is the connection for a backup battery (in the range 2.40 V to 4.15 V; typically 3.0 or 3.6 V). This battery is used by the cpuModule. Battery functions are described in the cpuModule's hardware manual.

Battery, B1			
Pin	Signal	Pin	Signal
1	Battery +	2	Battery -

Solder Jumper, B3 (to bypass battery protection diode)

To bypass the onboard battery protection diode, short pins one and two of solder jumper B3.

PC Speaker, SPK1 (Factory Installed)

A speaker is available on pins 1 and 2 of SPK1. These outputs are controlled by a transistor to supply 0.1 watt of power to an external speaker. The factory installed speaker has an impedance of 8 ohms and is connected between pins 1 and 2.

PC Speaker, SPK1			
Pin	Signal	Function	Input/Output
1	SPKR+	Speaker Output (open collector)	Output
2	KBP_SPKR-	Speaker output (+5 volts)	Output

PC/104 Bus Connectors, CN1 and CN2 (CMT36106 Only)

Connectors CN1 and CN2 provide PC/104 bus connections. CN1 carries XT bus signals, and CN2 carries additional signals for the AT bus. The signals on CN1 and CN2 conform to the IEEE P966 standard for the PC/104 bus. The CMT36106 only connects to the power pins of the PC/104 bus.

These connectors are described in a previous chapter.

EIDE Drive Connector, CN3

The function of CN3 is described in a previous chapter.

EIDE Stack through Connector, CN4

CN4 is a 44-pin 2mm DIL connector is the EIDE stack through connector. The pin out of this connector is the same as pins 1-44 of CN3.

EIDE Cable Connector, CN5

CN5 is a 40-pin 0.1" DIL connector is the EIDE cable connector. The pin out of this connector is the same as pins 1-40 of CN3.

Power Connector, CN6 (CMT56106 Only)

CN5 is a 12-pin 0.1" DIL connector.

Power Connector, CN6			
Pin	Signal	Function	Input/Output
1	GND	Ground	--
2	+5V	5V Supply	--
3	n.c.	Not Connected (Pass-through)	--
4	n.c.	Not Connected (Pass-through)	--
5	n.c.	Not Connected (Pass-through)	--
6	n.c.	Not Connected (Pass-through)	--
7	GND	Ground	--
8	+5V	5V Supply	--
9	GND	Ground	--
10	n.c.	Not Connected (Pass-through)	--
11	n.c.	Not Connected (Pass-through)	--
12	n.c.	Not Connected (Pass-through)	--

Chapter 6 GETTING TECHNICAL SUPPORT

For help with this product, or any other product made by RTD, you can contact RTD Embedded Technologies via the following methods:

Phone: +1-814-234-8087

E-Mail: techsupport@rtd.com

Be sure to check the RTD web site (<http://www.rtd.com>) frequently for product updates, including newer versions of the board manual and application software.

LIMITED WARRANTY

RTD Embedded Technologies, Inc. warrants the hardware and software products it manufactures and produces to be free from defects in materials and workmanship for one year following the date of shipment from RTD Embedded Technologies, INC. This warranty is limited to the original purchaser of product and is not transferable.

During the one year warranty period, RTD Embedded Technologies will repair or replace, at its option, any defective products or parts at no additional charge, provided that the product is returned, shipping prepaid, to RTD Embedded Technologies. All replaced parts and products become the property of RTD Embedded Technologies. Before returning any product for repair, customers are required to contact the factory for an RMA number.

THIS LIMITED WARRANTY DOES NOT EXTEND TO ANY PRODUCTS WHICH HAVE BEEN DAMAGED AS A RESULT OF ACCIDENT, MISUSE, ABUSE (such as: use of incorrect input voltages, improper or insufficient ventilation, failure to follow the operating instructions that are provided by RTD Embedded Technologies, "acts of God" or other contingencies beyond the control of RTD Embedded Technologies), OR AS A RESULT OF SERVICE OR MODIFICATION BY ANYONE OTHER THAN RTD Embedded Technologies. EXCEPT AS EXPRESSLY SET FORTH ABOVE, NO OTHER WARRANTIES ARE EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND RTD Embedded Technologies EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED HEREIN. ALL IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES FOR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS WARRANTY. IN THE EVENT THE PRODUCT IS NOT FREE FROM DEFECTS AS WARRANTED ABOVE, THE PURCHASER'S SOLE REMEDY SHALL BE REPAIR OR REPLACEMENT AS PROVIDED ABOVE. UNDER NO CIRCUMSTANCES WILL RTD Embedded Technologies BE LIABLE TO THE PURCHASER OR ANY USER FOR ANY DAMAGES, INCLUDING ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, EXPENSES, LOST PROFITS, LOST SAVINGS, OR OTHER DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PRODUCT.

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR CONSUMER PRODUCTS, AND SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

RTD Embedded Technologies, Inc.

103 Innovation Blvd.

State College PA 16803-0906

USA

Our website: www.rtd.com

Techsupport: techsupport@rtd.com

(814) 234-4626